EKSSPERIMENTAL
SOUNDS STUDIO

# EKSSBOX
# SIREN MKIII



**EKSSBOX SIREN MKIII** — MODE · PITCH · RATE · DEPTH · RATE TRIM · DEPTH TRIM · TRIG (OFF/ON) · KBD MODE (OFF/ON) · WAVE · DECAY · FILTER · VOL — EKSSPERIMENTAL SOUNDS STUDIO

**Thank you for choosing EKSSBOX Siren Mk3!**

The siren combines set states inspired by the classic NJD siren with timmers for rate and depth. It has a wave selector for chosing between Saw, Square and Triangular oscillator waveforms. It can be triggered by either the momentary action button, the switch or by keyboard.

When KBD mode is active the LFO will reset at each new trig and the pitch will scale along the keyboard, just like a synthesizer! The decay knob can add a decaying tail to the signal and the filter will cut low end to avoid rumble when played on big speaker boxes.

EKSSBOX Mk3 also has a special mode; "Mode 6"which is a Synare like effect. Pitch, rate and depth controls still works the same but the wave selector changes to choose between modulation waveform of the LFO, and the filter changes to set the base pitch of the effect.

EKSSBOX Mk3 support modwheel and pitchbend control, mod wheel will control the rate of the LFO and Pitchbend will shift the oscillator base pitch.

---

**SPECIFICATIONS**

6 Modes

2 oscillators

Trig switch

Trig action button

3 Wave modes

Decay & Filter for sound sculpting

Patch Browser for saving and loading patches